

# What color wire should be connected to Huawei solar inverter I1

This PDF is generated from: <https://www.artetmiss.us/Mon-06-Apr-2026-47530.html>

Title: What color wire should be connected to Huawei solar inverter I1

Generated on: 2026-07-08 21:52:28

Copyright (C) 2026 ARTEMISS SOLAR INFRA. All rights reserved.

For the latest updates and more information, visit our website: <https://www.artetmiss.us>

---

The battery cables should be connected correctly. That is, the positive and negative terminals of the battery connect to the positive and negative battery terminals on the SUN2000 ...

Connect cables in accordance with the local Installation laws and regulations. Before connecting cables, ensure that the DC switch of the solar inverter and all the switches connected to it are set to OFF. ...

Use the Staubli MC4 positive and negative metal terminals and DC connectors delivered with the inverter. Using incompatible positive and negative metal terminals and DC connectors may result in ...

Installing the AC Output Power Cable Ensure that the protective layer of the AC output power cable is inside the connector, that the core wires are totally ...

When the inverter is connected to two ESSs, the FE network cable between the ESSs must be connected, and an ESS needs to be connected to the EMMA or router through an FE network cable.

If the PE terminal is not connected to the AC connector, use a single-core outdoor copper cable with a conductor cross-sectional area of at least 10 mm<sup>2</sup> as the PE cable on the chassis.

Huawei single phase L1 inverters Device comms port L1 comms port Note Smart meter ->25 (B) 3 CT white to 5, 4 blue to 6 Battery 7 3 4 5 6 1P Backup Box 1 on X4 8 Shunt between 4 2 on X4 5 and 5 ...

o Connect cables in accordance with the local installation laws and regulations. o Before connecting cables, ensure that the DC switch of the solar inverter and all the switches

L1/LC0 can be cascaded and each L1/LC0 can connect to a maximum of two energy storage systems (ESSs). In the Smart Dongle networking scenario, a maximum of three inverters and six ESSs can ...



# What color wire should be connected to Huawei solar inverter I1

Web: <https://www.artetmiss.us>

